

USER'S MANUAL



RX-195 WIRELESS

www.sven.fi

RX-195 WIRELESS

Congratulations on purchasing the SVEN PC mouse!

Please read the following User's Manual carefully before connecting, operating or adjusting this product. Besides, please keep this Manual in a safe place for future reference.

COPYRIGHT

© 2014, SVEN PTE, LTD, Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information of this Manual is given on «as is» terms. The author and the publisher do not bear any liability to a person or an organization for loss or damages which have arisen from the information contained in the given Manual.

СОЛЕРЖАНИЕ

УДЕРЖАПИЕ	
1. SPECIAL FEATURES	2
2. PACKAGE CONTENTS	2
3. SYSTEM REQUIREMENTS	2
4. DESCRIPTION	3
5. INSTALLATION	3
6. TROUBLESHOOTING	5
7 TECHNICAL SPECIFICATION	_



1. SPECIAL FEATURES

- RF 2.4GHz USB nano receiver (range up to 10 m)
- · High-precision optical technology
- Effective on most surfaces
- High speed operation
- Resolution 800 dpi
- USB interface
- · 2 AAA Alkaline type batteries
- Drivers installation is not required for Windows XP/Vista/7/8
- . Natural shape of the mouse convenient for the hand
- Energy saving system increases battery life up to 6 months (see comparison table)

Operating mode	RX-195W	Other mice
During work	4.8 — 6 mA	10 mA
Motionless	0.5 — 0.55 mA	8 mA
Standby mode	0.1 — 0.12 mA	3 mA
Sleeping mode	0.03 — 0.05 mA	0.15 mA

2. PACKAGE CONTENTS

- Optical mouse 1 pc
- 2.4 GHz USB nano receiver 1 pc
- AAA type batteries 2 pcs
- User's Manual 1 pc
- Warranty card 1 pc

3. SYSTEM REQUIREMENTS

- Windows XP/Vista/7/8.
- · Free USB port.

RX-195 WIRELESS

4. DESCRIPTION

- 1 Scroll wheel
- 2 Battery compartment
- 3 Optical sensor
- USB connector
- Nano receiver




Fig. 2. Bottom view




Fig. 1. Top view



Fig. 3. Nano receiver

5. INSTALLATION

- Open the cover of the mouse battery compartment ②, insert two AAA type batteries into the battery compartment matching polarity, and close the cover of the battery compartment (see Fig. 4).
- Unpack the nano receiver

 and connect it to an available PC USB port
 (Fig. 5). To activate the mouse, it is necessary to press any button of the mouse or scroll the wheel. If the mouse has been connected correctly, it will turn on automatically.






Fig. 4. Installation of batteries

- Do not place the receiver in confined metal space (table drawer, box, safe), as a metal screen does not transmit radio signals.
- If the batteries run down, the mouse works by fits. It means that batteries should be replaced with new ones, as it is shown in Fig. 4. Always install only identical new batteries.



Fig. 5. Receiver connection

Important

This device meets highest standards of energy conservation. During long pauses in operation the mouse enters the economical Sleep mode. To enter the working mode, just press any button or scroll the wheel.

6 TROUBLESHOOTING

Problem	Solution
The mouse does not work.	Make sure that the nano receiver has been inserted into the USB port and its distance to the mouse is less than 10 m. Check whether the batteries have been installed correctly. Check if the batteries have run down, replace them with new ones if necessary.
Batteries are in good order, but the mouse still does not work.	Install software to coordinate the mouse and the receiver. Software can be down- loaded from Support on www.sven.fi

7. TECHNICAL SPECIFICATIONS

Parameter	Value
OS compatibility	Windows XP/Vista/7/8
Type of mouse	wireless 2.4 GHz
Resolution, dpi	800
Q-ty of buttons	2 + 1 (scroll wheel)
Interface	USB
Conformity with	FCC, CE

Notes:

- Technical specifications given in this table are supplemental information and cannot give occasion to claims.
- Technical specifications are subject to change without notice due to improvement of SVEN production.





Модель: RX-195 Wireless

Импортер в России: ООО «СКАНДИТРЕЛ», 111024, РФ, г. Москва, ул. Авиамоторная, д. 65, стр. 1. Уполномоченная организация в России:

ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха Энгельса, д. 75, стр. 5.

Условия гарантийного обслуживания смотрите в гарантийном талоне или на сайте www.sven.fi. Гарантийный срок: 12 мее. Срок службы: 2 года. Производитель: «СВЕН ПТЕ. Лимитед», 176 Джу Чиат Роуд. № 02-02, Сингапур, 427447.

176 Джу Чиат Роуд, № 02-02, Сингапур, 427447. Произведено под контролем «Свен Скандинавия Лимитед», 48310, Финляндия, Котка, Котолахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD., 176 Joo Chiat Road, № 02-02, Singapore, 427447. Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.

® Registered Trademark of Oy SVEN Scandinavia Ltd. Finland. RX-195 WIRELESS