

SVEN[®]

Portable Radio

USER MANUAL



SRP-755

www.sven.fi

Congratulations on your purchase of the SVEN portable radio!

COPYRIGHT

© 2020. SVEN PTE. LTD. Version 1.0 (V 1.0).

This manual and information contained in it are copyrighted. All rights reserved.

BUYER RECOMMENDATIONS

- Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.
- Shipping and transportation equipment is permitted only in the original container.
- Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.

APPLICATION

SVEN SRP-755 portable radio with Bluetooth is designed for operation with PC, notebooks and other mobile devices by means of data transfer via Bluetooth protocol. It can be also used in internet telephony, during video conferences, in multimedia applications, in interactive games. FM/AM/SW-tuner and the player with USB-flash and micro SD-cards are included.

PACKAGE CONTENTS

- Portable radio – 1 pc
- Mini-jack to mini-jack signal cable – 1 pc
- USB to micro USB power cable – 1 pc
- User Manual – 1 pc
- Warranty card – 1 pc

SPECIAL FEATURES

- Bluetooth wireless signal transmission
- Radio dial light
- Built-in FM/AM/SW tuner
- Wired connection
- Built-in player for audio files from USB-flash and microSD card
- Telescopic swivel antenna
- Built-in battery

Technical support is on www.sven.fi.

Description

- ① Telescopic swivel antenna
- ② MODE  : switching modes button Player/AUX/Bluetooth (short pressing); repeat mode selection button (long pressing in Player mode):
- to repeat the current track (frequent flashing LED on the front panel)
- to play all tracks (rare flashing blue LED on the front panel)
- ③ Previous track (in Player and Bluetooth mode)
- ④ Play/Pause (in Player and Bluetooth mode)
- ⑤ Next track (in Player and Bluetooth mode)
- ⑥ Station tuning knob
- ⑦ Volume control
- ⑧ Mode control (Player/AUX/Bluetooth/FM/AM/SW Radio)
- ⑨ USB-flash card slot
- ⑩ AUX: 3.5 mm mini-jack for audio signal connecting (phone, MP3 player, etc.)
- ⑪ MicroSD card slot
- ⑫ Power switch
- ⑬ LED charge indicator
- ⑭  5V: connector for charging from 5V charger




Fig. 1.

CONNECTION AND OPERATION

Attention! The built-in battery must be charged completely prior to the application.

Battery charging

- Connect radio to a USB port of PC or USB charger using micro USB to USB cable (included). During battery charging the indicator ⑬ is red. Indicator ⑬ goes out when the battery is charged.
- The battery is used in the speaker system as an integral part of the device, therefore do not try to extract or replace it, because this can result in the warranty cancellation or the device damage.

OPERATION MODES

Bluetooth mode

- Wireless data transfer via the Bluetooth protocol enables to connect radio to compatible devices. Maximum radius of action of data transfer is 10 m. Such obstacles as walls or other electronic devices can interfere with the signal transfer.
- Turn on the speaker into Bluetooth mode, set the ④ switch to BT / MP3.
- It is necessary to select the search mode of devices with Bluetooth on a signal source (telephone, notebook, smartphone, etc.). «SRP-755», message will be displayed on the screen which is to be connected to*.
- When connection is successful, there will be a short beep and the indication of the search mode on radio is over**.

Radio mode

- Turn on the portable radio into Radio mode – set the ④ switch to FM/AM/SW.

Player mode

Attention! The file system of a micro SD carrier is FAT32. Maximum volume is 32 GB. It is not recommended to use the micro SD Ultra Speed.

- The radio will enter the Player mode automatically when a carrier (USB flash or SD card) is connected to corresponding ports. Use button ④ to switch between Play / Pause modes. You can control tracks by using buttons ③ (previous track) and ⑤ (next track).

* You might have to enter “0000” code to connect some models of devices via Bluetooth.

** If the item has been already registered in the device list of a source, then the second search mode activation is not obligatory. Choose the item name «SRP-755» and the “connect” command on the source.




Fig. 2. Connection diagram

The use in the wired mode (AUX)

- Portable radio can be used as an external device for amplifying any audio source with a 3.5 mm output mini-jack.
- Turn the radio into AUX mode, set the switch  to BT/MP3 position.
- Connect the 3.5 mini-jack cable to the audio input AUX.

TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Frequency range, Hz	120 – 20 000
Output power (RMS), W	8
Speaker diffuser diameter, mm	Ø 90
Power supply	lithium-ion battery, mAh - 1500/USB-  5V
Rated current (230V), A	0.13
Weight, kg	1.00
Dimensions, mm	260 × 180 × 100

Notes:

- **Technical specifications given in this table are supplemental information and cannot give occasion to claims.**
- **Technical specifications and package contents are subject to change without notice due to the improvement of SVEN production.**

Portable Radio

SVEN®



Model: SRP-755

Импортер в России: ООО «Регард», 105082, г. Москва, ул. Фридриха Энгельса, д. 75, стр. 5. Уполномоченная организация в России: ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха Энгельса, д. 56, стр. 1. Условия гарантийного обслуживания смотрите в гарантийном талоне или на сайте www.sven.fi.

Гарантийный срок: 12 мес.

Срок службы: 2 года

Производитель: «СВЕН ПТЕ. Лимитед», 176 Джу Чиаг Роуд, № 02-02, Сингапур, 427447. Произведено под контролем «Свен Скандинавия Лимитед», 48310, Финляндия, Котка, Котolahdentie, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road, № 02-02, Singapore, 427447. Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotalahdentie, Kotka, Finland, 48310. Made in China.

© Registered Trademark of Oy SVEN Scandinavia Ltd. Finland.



SRP-755